



Operating instructions

IMPORTANT SAFEGUARDS
When using an electrical appliance, basic precautions should always be followed, including the points listed below. Read all instructions and safeguards before using the appliance.

- WARNING**
To reduce the risk of injury or death by electric shock:
- Do not reach for an appliance that has fallen into water. Unplug immediately from the outlet.
 - Do not use while bathing or in a shower.
 - Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place it in or drop into water or other liquid.
 - Always unplug this appliance before the electrical outlet immediately after using.
 - Avoid use of this appliance before drying.

WARNING

- To reduce the risk of burns, fire, electric shock or injury to persons:
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.**
- Warning: Keep the Product Dry.** It is essential to PREVENT electrical equipment from coming into contact with water or other liquids.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Keep the cord away from heated surfaces.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use the appliance with a damaged or broken cord nor with wires missing from the blades, as injury may occur.

SAVE THESE INSTRUCTIONS

This appliance is not designed for household use.

- A - Bottom blade
B - Blade slide (on Multi-cut (MC) clipper only)
C - Taper lever (on Multi-cut (MC) clipper only)

- D - Switch
E - Top blade
F - Power screw

CLIPPER MAINTENANCE

Your Wahl clipper blades were oiled and aligned before leaving our factory; however, it is possible for blades to get bumped out of alignment. Blades must be realigned if they have been removed for cleaning or replacement. To determine if realignment is necessary, compare your clipper blades with diagram G.

- If your clipper has a taper lever, position the taper lever in the close cut position. (H)
- End of top blade teeth should be approximately 1/32" (64 mm) back from bottom blade. This is important so that the clipper does not cut too close or allow the moving cutter to touch the skin.
- Extreme left-hand tooth of top blade must be covering or to the left of the first small tooth of bottom blade.

- Extreme right-hand tooth of top blade must be touching the big tooth on the bottom blade.
- If blade alignment is incorrect, add a few drops of Wahl Clipper Oil to the blades, turn clipper "On" for a few moments, turn "Off" and unplug. Loosen screws slightly and adjust (steps 2-3 listed above). Tighten screws after blades are aligned. Other than blades this clipper has no user serviceable parts. (diagram I)

OIL (I)

The blades of your new clipper should be oiled every few haircuts. Simply place a few drops of Wahl Clipper Oil on the teeth of the blades. Use only the Wahl Clipper Oil included in the pack. Due to the high speed of your Wahl clipper, the correct type of oil must be used. Do not use hair oil, grease or any oil mixed with kerosene or any solvent, as the solvent will evaporate and leave the thick oil, slowing down the blades. Wahl Clipper Oil is a very thin, natural oil which will not evaporate and will not stick on the blades.

POWER SCREW (Not found on all models of Wahl Clippers)

Your clipper has a power screw, used to adjust the power efficiency before leaving the factory. However, if voltage in your home is low, you may need to readjust it. To adjust power, use the plastic brush, a screwdriver or a thin coin to turn power screw in a clockwise direction until the arm strikes the coil, making a noise. Then, slowly turn power out (counterclockwise), just until noise stops. Turn to the maximum power setting. (K)

CORD

The cord should not be used to pull the clipper. Since freedom of movement needs to be maintained, care should be used to keep the cord untwisted and unobstructed. When stored, the cord should be coiled and the unit placed in original box or storage pouch (if provided).

If your clipper has a polarized plug: To reduce the risk of electric shock, this appliance has a polarized plug which will only fit one way. If it does not fit in one way, do not force it. In the event the plug does not fit fully in the outlet, reverse the plug. In the event it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

TAPER LEVER (Not found on all models of Wahl Clippers)

If your clipper has an adjustable taper lever, it is conveniently located near your thumb (if you're right-handed), so it can easily be adjusted. The taper lever is used to gradually change the closeness of your cut without a guide comb. When the lever is in the uppermost position, the blades will give you the closest cut and leave the hair very short. (diagram H) Pushing the lever downward gradually increases the cutting length. In its lowest position, the taper lever will leave the hair approximately the same length as the 1/8" guide comb. (diagram K2)

The taper lever will also extend the use of your blades since a different cutting edge is used in each setting. In addition, if extremely heavy haircutting has jammed the blades, it will help you remove hair that has become wedged between the blades without the need to turn the clipper. To remove hair, turn the clipper from "close cut" to "longer cut" a couple of times. Doing this each time you've finished using your clipper will help keep the blades clear of hair. If your clipper stops cutting and this does not help, your cutting blades may be dull. Either replace them or return them to Wahl for sharpening.

WAHL'S GUIDE TO FOOLPROOF HOME HAIRCUTTING

Before you cut your hair

- 2 yr kit includes a plastic cape, used to protect your neck during the work, tying the strings and overlapping the cape portion to prevent hair from falling down inside the collar. If no cape is provided, a towel will do as well.
- Position the person whose hair is to be cut on a stool or chair so that the top of his head is about even with your eyes.
- After combing the hair to remove all tangles, hold the clipper in a relaxed, comfortable grip, with the ramplate (the comb) facing the hair to be cut. The clipper will help you maintain control, accurate cutting and control.

NOTE: To attach guide combs, hold comb with the teeth up. Snap guide comb attachment firmly to the bottom of the clipper blade. (L)

Depending on the kit you purchased your kit may include one of the following:

Adjustable Guide Combs - allowing multiple cutting lengths in the convenience of a single comb.
Individual Color Guide Combs - providing predetermined lengths indicated on each guide comb.
Individual Color Guide Combs - providing predetermined lengths indicated on each guide comb. Combs are also color coded for quick cutting length reference.

Using adjustable guide combs:

The small adjustable guide comb has five settings from 1/8" to 5/8" (3mm to 16mm) in 1/8" (3mm) increments. (M)
The large adjustable guide comb has five settings from 3/4" to 1-1/4" (19mm to 32mm) in 1/8" (3mm) increments. (N)

Using your thumb, you can change the length of the cut by simply sliding the adjustable lever to the next position. Both adjustable guide combs have positive click stops and indicators that show position number and cutting length in millimeters for quick and easy setting identification.

The large adjustable guide comb can be used from the ear to the crown of the head. (O1)
The small adjustable guide comb can be used from the nape to the ear area. (O2)

Using individual (black or colored) guide combs:

Some kits do not include all Wahl guide combs. However, any of these combs (or additional accessories not listed here) may be available from your dealer or can be ordered directly from Wahl.

INDIVIDUAL GUIDE COMB SETTINGS:

- | | |
|--------------------------------|-------------------------------|
| • 3mm - Black/Red | • 6mm - Black/Purple |
| • 10mm - Black/Dark Blue | • 13mm - Black/Orange/Pink |
| • 16mm - Black/Yellow | • 19mm - Black/Lavender |
| • 22mm - Black/Green | • 25mm - Black/Light Blue |
| • 28mm - Black/White | • 31mm - Black/White |
| • Right Ear Taper - Black only | • Left Ear Taper - Black only |

CUTTING HAIR

FOR MEDIUM TO LONG CUTS: (P)

The first time you cut your hair, cut only a small amount until you become accustomed to how long each guide comb leaves the hair. Cutting over the guide comb on the clipper, then use shorter combs (or settings - if using adjustable guide combs) if a shorter length is desired.

Remember, between professional haircuts, the hair grows evenly all over the head and a light trimming at the lower neck and sides may be all that is needed to bring back that well-kept, roomy look.

For uniform cutting, allow the clipper to cut its way through the hair. Do not force it through at a faster rate.

- Start by combing the hair so it falls into its natural direction.
- Place the largest guide comb onto your clipper and start by trimming the sides from the bottom upwards. Hold the clipper lightly against the hair, with teeth of the guide comb pointing up but flat against the head. Slowly lift the clipper up and over the hair, cutting only a small amount at a time.

Repeat around sides and back of head.

If you desire shorter hair, either change to a shorter guide comb (or setting - if using adjustable guide combs) or apply more pressure and less lift away from the head with the present attachment. This entire procedure requires practice, and it is always better to leave too much hair than the first few haircuts. For the top of the head, you may give a fairly short cut if you use the 1" guide comb (or setting - if using 1/4" or 1-1/2" guide comb, you may use this for a slightly longer cut). With the teeth flat against the head, slowly start trimming from the front to the back. Again, it is better to leave the hair longer the first few haircuts.

FOR LONGER HAIR: IT TOPPER

By using a guide comb, a longer cut can be achieved. Use either a barber comb or regular comb and lift the hair from the back of the head, cutting over the guide comb on the clipper, then use shorter combs (or settings - if using adjustable guide combs) if a shorter length is desired.

Remember, between professional haircuts, the hair grows evenly all over the head and a light trimming at the lower neck and sides may be all that is needed to bring back that well-kept, roomy look.

For uniform cutting, allow the clipper to cut its way through the hair. Do not force it through at a faster rate.

- Start by combing the hair so it falls into its natural direction.
- Place the largest guide comb onto your clipper and start by trimming the sides from the bottom upwards. Hold the clipper lightly against the hair, with teeth of the guide comb pointing up but flat against the head. Slowly lift the clipper up and over the hair, cutting only a small amount at a time.

Repeat around sides and back of head.

If you desire shorter hair, either change to a shorter guide comb (or setting - if using adjustable guide combs) or apply more pressure and less lift away from the head with the present attachment. This entire procedure requires practice, and it is always better to leave too much hair than the first few haircuts. For the top of the head, you may give a fairly short cut if you use the 1" guide comb (or setting - if using 1/4" or 1-1/2" guide comb, you may use this for a slightly longer cut). With the teeth flat against the head, slowly start trimming from the front to the back. Again, it is better to leave the hair longer the first few haircuts.

FOR LONGER HAIR: IT TOPPER

By using a guide comb, a longer cut can be achieved. Use either a barber comb or regular comb and lift the hair from the back of the head, cutting over the guide comb on the clipper, then use shorter combs (or settings - if using adjustable guide combs) if a shorter length is desired.

Remember, between professional haircuts, the hair grows evenly all over the head and a light trimming at the lower neck and sides may be all that is needed to bring back that well-kept, roomy look.

For uniform cutting, allow the clipper to cut its way through the hair. Do not force it through at a faster rate.

- Start by combing the hair so it falls into its natural direction.
- Place the largest guide comb onto your clipper and start by trimming the sides from the bottom upwards. Hold the clipper lightly against the hair, with teeth of the guide comb pointing up but flat against the head. Slowly lift the clipper up and over the hair, cutting only a small amount at a time.

Repeat around sides and back of head.

If you desire shorter hair, either change to a shorter guide comb (or setting - if using adjustable guide combs) or apply more pressure and less lift away from the head with the present attachment. This entire procedure requires practice, and it is always better to leave too much hair than the first few haircuts. For the top of the head, you may give a fairly short cut if you use the 1" guide comb (or setting - if using 1/4" or 1-1/2" guide comb, you may use this for a slightly longer cut). With the teeth flat against the head, slowly start trimming from the front to the back. Again, it is better to leave the hair longer the first few haircuts.

TAPERING AROUND EARS:

USING LEFT AND RIGHT EAR GUIDE COMBS:
The adjustable guide comb can be used from the ear to the crown of the head. (O1)
By using the outline of the ear with the appropriate comb you achieve a gradual taper blending without having to use multiple combs.

TO TAPER THE AREA BORDERING THE LEFT EAR:
Attach the Left Ear Taper Comb to your clipper and stand facing the left ear. While holding the clipper at a slight angle attach the head, position the guide comb just back of the left ear at the hairline. Then move the clipper in a small hair circle pattern around the ear until you are toward the front of the head. Depending on the length of hair you are working with you may need to take several small strokes as you proceed around the ear. When doing so, slowly move the clipper upward and outward being mindful of the result. This will allow you to guide hair into the comb towards the clipper blades.

Note: You may also achieve a tapering of sideburns by including the sideburn area as you begin to move the clipper around the ear.

TO TAPER THE AREA BORDERING THE RIGHT EAR:

Attach the Right Ear Guide Comb to your clipper. Stand facing the right ear and repeat the process described above for the left ear.

Finish by holding the area around the ear as described in the following section.

OUTLINING: (R)

Not all attachments are needed. (On a multi-cut clipper, push the taper lever up to the "close-cut" position). Comb hair into desired style. Starting between the ear and the sideburns, as shown at left, hold clipper with corner edge of blade against the hairline. Slowly follow the desired outline of the hair over, around and behind the ears. For finishing sideburns and the back of the neck, hold the clipper with the comb at the desired length and move down.

Comb hair and check that sides are even. Check for uneven spots throughout the haircut.

CREW CUTS AND SHORT CUTS (R)

Starting with the longest guide comb, cut from the back of the neck to the crown. Hold the guide comb flat against the head and slowly move the clipper through the hair, as shown.

Use the same procedure to trim the upper side of the head, as shown. Then cut the hair against the direction in which it grows, from the front to the crown, and even up to the cut with the sides.

To give a "flat-top" look, the hair on top of the head must be cut over the top of a flat comb, rather than using the guide comb.

Use clippers using guide combs to "taper" the hair down to the neckline, as desired. Comb hair and check for uneven spots. Outline sideburns and neckline as previously described.

If a short, tapered cut on the sides and back is desired, follow diagram S.

The five basic areas illustrated on the Wahl haircutting guide are your "road map" to easy, do-it-yourself haircutting. For tips on the latest trends and fashions in haircutting, visit us at www.wahl.com.

If you reside within the EU and your unit is marked with the following symbol  do not discard in trash. This product is to be returned to the appropriate municipal waste collection facility for recycling and recovery.

Gebrauchsanweisung

WICHTIGE SICHERHEITSHINWEISE

Beim Gebrauch eines Elektrogerätes sollten immer grundlegende Vorsichtsmaßnahmen beachtet werden, insbesondere die folgenden aufgeführten. Lesen Sie vor Gebrauch alle Anweisungen und Sicherheitshinweise sorgfältig durch.

- GEFÄHR**
Vermeiden Sie das Risiko einer Verletzung oder des Todes durch einen elektrischen Schlag.
- Greifen Sie nicht nach einem ins Wasser gefüllten Gerät. Ziehen Sie den Stecker aus der Steckdose.
 - Verwenden Sie das Gerät nicht in der Badewanne oder unter der Dusche.
 - Platzieren Sie das Gerät niemals in einem Behälter mit Wasser oder in einer Wanne füllt oder gezeugen werden könnte. Touchen Sie das Gerät nicht in Wasser oder anderen Flüssigkeiten und lassen Sie sich nicht dort hängen fallen.
 - Ziehen Sie außer wenn Sie das Gerät aufladen, nach jedem Gebrauch den Stecker des Gerätes aus der Steckdose.
 - Ziehen Sie vor dem Reinigen des Gerätes immer den Stecker aus der Steckdose.

WARNING

To Reduce the Risk of Verletzungen, Brûlures, Électrocution et Mortalité:

- Dieses Gerät kann von Kindern ab 8 Jahren und Personen mit eingeschränkter physischer, sensorischer oder geistiger Fähigkeiten oder Personen mit mangelnder Erfahrung und Wissen verwendet werden, solange dies unter Beaufsichtigung erfolgt oder sie die notwendige Anleitung zum sicheren Umgang mit diesem Gerät erhalten haben und über die damit verbundenen Gefahren informiert sind. Dieses Gerät darf von Kindern nicht als Spielzeug verwendet werden. Reinigung und Wartung dürfen von Kindern nur unter angemessener Aufsicht durchgeführt werden.
- Warnung:** Halten Sie das Gerät trocken. Es ist äußerst wichtig zu VERHINDERN, dass Elektrogeräte in Kontakt mit Wasser oder anderen Flüssigkeiten kommen.

PRECAUTIONS IMPORTANTES

Lorsque vous utilisez un appareil électrique, les précautions de base doivent toujours être suivies, y compris les recommandations données ci-dessous. Lisez toutes les instructions et précautions avant toute utilisation.

DANGER

- Évitez le risque de blessure ou de mort par électrocution.
- N'utilisez pas de reprends un appareil tombé dans l'eau. Débranchez-le immédiatement de la prise de courant.
- N'utilisez pas l'appareil dans votre bain ou sous la douche.
- Placerez jamais l'appareil dans un récipient qui puisse tomber à l'eau ou accidentellement poussé dans une baignoire ou un lavabo. Ne le placez pas et ne le laissez pas tomber dans l'eau ou dans un autre liquide.
- Sauf lors de son rechargement, débranchez toujours l'appareil de la prise électrique immédiatement après l'utilisation.
- Débranchez toujours l'appareil avant de le nettoyer.

AVERTISSEMENT

Pour réduire le risque de brûlures, d'électrocution ou de blessures :

- Cet appareil peut être utilisé par des enfants âgés de 8 ans et plus et par des personnes de capacités physiques, sensorielles ou mentales réduites, ou qui manquent d'expérience et de connaissances, à condition que ces personnes bénéficient d'une surveillance ou d'instructions concernant l'utilisation sécurisée de l'appareil, et qu'elles comprennent les risques que cette utilisation implique. Les enfants ne doivent pas jouer avec l'appareil. Le nettoyage et l'entretien ne doivent pas être effectués par des enfants sans surveillance.
- Avvertissement :** gardez le produit au sec. Il est indispensable d'ÉVITER l'équipement électrique d'entrer en contact avec de l'eau ou d'autres liquides.

* Utilisez cet appareil uniquement pour l'usage auquel il est destiné, comme décrit dans ce manuel. N'utilisez pas d'accessoire non recommandé par le fabricant. Lisez toutes les instructions et précautions avant toute utilisation.

- N'utilisez jamais cet appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.
- N'utilisez jamais l'appareil si le cordon ou la prise d'alimentation sont endommagés, ou si le fonctionnement pas correctement, même après avoir réparé le problème.

CONSERVER CES INSTRUCTIONS

La tondeuse à été conçue pour un usage à domicile.

- | | |
|---|---------------------|
| A - Lame inférieure | D - Commande |
| B - Glissière de lame (sur la tondeuse Multi-cut (MC) uniquement) | E - Lame supérieure |
| C - Levier de réglage (sur la tondeuse Multi-cut (MC) uniquement) | F - Vis électrique |

ENTRETIEN DE LA TONDEUSE

Les lames de la tondeuse Wahl doivent être huilées et alignées au début de l'usage ; cependant, elles peuvent sortir de leur alignement et elles doivent être retirées, les lames doivent être réalignées pour nettoyer ou remplacement. Pour déterminer si un réalignement est nécessaire, comparez les lames de la tondeuse avec celles figurant sur l'illustration. (G)

- La tondeuse est équipée d'une lame supérieure de réglage, le placer en position de coupe rap proche. (H)
- L'extrémité des dents de la lame supérieure doit être à environ 0,64 mm (1/32 de pouce) de la lame inférieure. Ceci est important pour éviter que la tondeuse ne coupe trop près et que la lame molle ne touche la peau.
- La dent à l'extrême gauche de la lame supérieure doit couvrir ou être à la gauche de la première dentelle de la lame inférieure.

- La dent à l'extrême droite de la lame supérieure doit toucher la grande dent de la lame inférieure.
- Si l'alignement de la lame est incorrect, ajuster quelques gouttes d'huile pour tondeuse à cheveux Wahl sur les lames, mettre la tondeuse en marche pendant quelques instants puis débrancher. Desserrer légèrement les vis et régler (étapes 2-3 indiquées ci-dessus). Serrer les vis après que les lames ont été alignées. À l'exception des lames, cette tondeuse ne comporte aucune pièce réparables par l'utilisateur.

HUILE (I)

Les lames de la tondeuse doivent être huilées périodiquement après quelques utilisations. Placer simplement quelques gouttes d'huile pour tondeuse à cheveux Wahl sur les dents des lames. Rutiliser l'huile pour tondeuse à cheveux Wahl inclus dans l'emballage. En raison de la vitesse élevée de la tondeuse Wahl, utiliser le type correct d'huile. Ne pas utiliser d'huile pour moteur, de graisse ou d'huile mélangée avec du kérosène ou d'autres solvants. Ce dernier évapore et laisse des résidus d'huile épaisse, qui ralentissent les lames. L'huile pour tondeuse à cheveux Wahl est une huile naturelle très fine qui ne s'évapore pas et ne ralentit pas les lames.

VIS ÉLECTRIQUE (non disponible sur tous les modèles de tondeuses à cheveux Wahl)
Les tondeuses équipées d'une vis électrique sont réglées au début de l'usage pour fournir des performances optimales. Cependant, si la tension de votre habitation est faible, il peut être nécessaire de la régler.

Pour régler la puissance, utiliser la brosse en plastique, un tournevis ou une pièce de monnaie fine pour tourner le bouton jusqu'à ce que le bras tourne jusqu'à ce que le bras touche la bobine en faisant un bruit. Tourner le bouton vers la vis (extérieur (dans le sens antihoraire) jusqu'à ce que le bruit s'arrête. Ceci correspond au réglage de puissance maximum. (K)

CORDON

Le cordon doit pas être utilisé pour tirer la tondeuse. Pour conserver une liberté de mouvement, prendre soin de maintenir le cordon déroulé et non obstrué. Pour ranger le cordon, l'enrouler et placer l'unité dans sa boîte d'origine ou dans sa pochette de remise à l'équipement. (J)

Si la tondeuse a une fiche polarisée. * Pour réduire le risque de chocs électriques, cet appareil a une fiche polarisée à deux broches (type I) et une fiche non polarisée à deux broches (type II). Ce type de fiche est conçu pour tondeuse à cheveux Wahl. Dans le cas où cette fiche ne s'adapte pas entièrement dans la prise, inverser la fiche. Si elle ne s'adapte toujours pas, faire appel à un électricien qualifié pour installer la prise adéquate. Ne modifier la fiche en aucune façon.

LEVIER DE RÉGLAGE

La tondeuse est équipée d'un levier de réglage, celui-ci est placé de façon pratique près du pouce (pour les droitiers) pour permettre de la régler facilement dans le main.

Le levier de réglage ajoute une fonction de réglage à la tondeuse en modifiant la longueur de la coupe sans avoir besoin d'utiliser une guide-combe. Le levier de réglage à été conçu pour être utilisé avec des lames réglées à une bord de coupe différent. En outre, si les lames sont bloquées par la coupe épaisse il n'est pas nécessaire retirer les lames pour débrancher les cheveux. Lorsque la tondeuse est en marche, faire passer le levier rapidement de « coupe rapide» à « coupe plus longue » ou sur trois fois. Cette opération permet également de nettoyer les lames une fois la coupe terminée. Si la tondeuse arrête de couper et si cette opération ne permet pas de régler le problème, c'est que les lames sont émoussées. Les remplacer ou les renvoyer à Wahl pour affûtage.

REMARQUE: Pour fixer les peignes-guides, tenir le peigne avec les dents vers le haut. Enclencher fermement le peigne-guides sur la base de la lame de la tondeuse. (L)

Selon le kit acheté, celui-ci peut inclure l'un des éléments suivants :

1. **Peignes-guides réglables** – pour obtenir des longueurs de coupe avec un seul peigne.
Peignes-guides noirs individuels – pour des longueurs de coupe prédéterminées sur chaque peigne-guide.
Peignes-guides individuels de couleur – pour des longueurs de coupe prédéterminées sur chaque peigne-guide. Les différentes couleurs des peignes permettant également de reconnaître rapidement les différentes longueurs de coupe.

REMARQUE: Pour fixer les peignes-guides, tenir le peigne avec les dents vers le haut. Enclencher fermement le peigne-guides sur la base de la lame de la tondeuse. (L)

Le levier de réglage ajoute une fonction de réglage à la tondeuse en modifiant la longueur de la coupe sans avoir besoin d'utiliser une guide-combe. Le levier de réglage à été conçu pour être utilisé avec des lames réglées à une bord de coupe différent. En outre, si les lames sont bloquées par la coupe épaisse il n'est pas nécessaire retirer les lames pour débrancher les cheveux. Lorsque la tondeuse est en marche, faire passer le levier rapidement de « coupe rapide» à « coupe plus longue » ou sur trois fois. Cette opération permet également de nettoyer les lames une fois la coupe terminée. Si la tondeuse arrête de couper et si cette opération ne permet pas de régler le problème, c'est que les lames sont émoussées. Les remplacer ou les renvoyer à Wahl pour affûtage.

REMARQUE: Pour fixer les peignes-guides, tenir le peigne avec les dents vers le haut. Enclencher fermement le peigne-guides sur la base de la lame de la tondeuse. (L)

Selon le kit acheté, celui-ci peut inclure l'un des éléments suivants :

1. **Peignes-guides réglables** – pour obtenir des longueurs de coupe avec un seul peigne.
Peignes-guides noirs individuels – pour des longueurs de coupe prédéterminées sur chaque peigne-guide.
Peignes-guides individuels de couleur – pour des longueurs de coupe prédéterminées sur chaque peigne-guide. Les différentes couleurs des peignes permettant également de reconnaître rapidement les différentes longueurs de coupe.

REMARQUE: Pour fixer les peignes-guides, tenir le peigne avec les dents vers le haut. Enclencher fermement le peigne-guides sur la base de la lame de la tondeuse. (L)

Selon le kit acheté, celui-ci peut inclure l'un des éléments suivants :

1. **Peignes-guides réglables** – pour obtenir des longueurs de coupe avec un seul peigne.
Peignes-guides noirs individuels – pour des longueurs de coupe prédéterminées sur chaque peigne-guide.
Peignes-guides individuels de couleur – pour des longueurs de coupe prédéterminées sur chaque peigne-guide.

